

# Instructions for Use

## CHAMPION INDUSTRY CORP. LTD

No. 315, South Zhongshan Road, Nanjing, Jiangsu, China

Product Name: Occupational Footwear KNEE BOOT

Standard: EN ISO 20347:2022+A1:2024

PPE Regulation: Regulation (EU) 2016/425

Brand: INTER, INTERTOOLS

Model No.: 82812

Production Date: xx/xxxx

Lot:xxx

This is Class II occupational footwear complying with EN ISO 20347:2022+A1:2024, performance category OB with additional SR slip resistance.

### Intended use

This footwear protects against slip hazards on smooth floors and water ingress. Suitable for general wet-area working scenarios.

### Limitation of use

 This footwear provides NO protection against toe impact, compression or sharp-object penetration.  
Not for heavy oil, strong acid and strong chemical working conditions.

### Inspection before use

Inspect boots for cracks, tears, damage of outer sole before every use.  
Do not use if damaged.

### Cleaning & Maintenance

- Clean surface with mild soap and cool clean water.
- Do not use organic solvents, gasoline or corrosive detergents.
- Rinse thoroughly and dry naturally in ventilated shade place.  
Do not expose to direct sunlight or heat sources.

### Storage

Store in cool, dry and ventilated environment, away from ozone, heat, oil and sharp objects.

### Service life

Service life depends on working conditions. Replace immediately if cracks, hardening, sole wear-out appear.

**Caution:** The footwear should be fit checked prior to each wearing. EU declaration of conformity present on the website: [www.inter-tools.gr](http://www.inter-tools.gr)

PPE Regulation 2016/425

EN ISO 20347:2022+A1:2024 OB SR

# Οδηγίες Χρήσης

## CHAMPION INDUSTRY CORP. LTD

No. 315, South Zhongshan Road, Nanjing, Jiangsu, China

Όνομα Προϊόντος: Υποδήματα ΜΠΟΤΑ ΓΟΝΑΤΟΥ

Πρότυπο: EN ISO 20347:2022+A1:2024

Κανονισμός ΜΑΠ: Κανονισμός (ΕΕ) 2016/425

Μάρκα: INTER, INTERTOOLS

Αρ. Μοντέλου: 82812

Ημερομηνία Παραγωγής: xx/xxxx

Παρτίδα: xxx

Αυτά είναι υποδήματα Κλάσης II που συμμορφώνονται με το EN ISO 20347:2022+A1:2024, κατηγορία απόδοσης OB με πρόσθετη αντοχή στην ολίσθηση SR. .

### Προβλεπόμενη χρήση

Αυτά τα υποδήματα προστατεύουν από κινδύνους ολίσθησης σε λεία δάπεδα και από τη διείσδυση νερού. Κατάλληλα για γενικά σενάρια εργασίας σε υγρές περιοχές.

### Περιορισμός χρήσης

 Αυτά τα υποδήματα ΔΕΝ παρέχουν προστασία από κρούση δακτύλων, συμπίεση ή διείσδυση αιχμηρών αντικειμένων. Όχι για συνθήκες εργασίας με βαριά ορυκτέλαια, ισχυρά οξέα και ισχυρά χημικά.

### Επιθεώρηση πριν τη χρήση

Επιθεωρήστε τις μπότες για ρωγμές, σχισίματα, ζημιά της εξωτερικής σόλας πριν από κάθε χρήση. Μην τις χρησιμοποιείτε εάν έχουν υποστεί ζημιά.

### Καθαρισμός & Συντήρηση

- Καθαρίστε την επιφάνεια με ήπιο σαπούνι και κρύο καθαρό νερό.
- Μην χρησιμοποιείτε οργανικούς διαλύτες, βενζίνη ή διαβρωτικά απορρυπαντικά.
- Ξεπλύνετε σχολαστικά και στεγνώστε φυσικά σε αεριζόμενο σκιερό μέρος.  
Μην εκθέτετε σε άμεσο ηλιακό φως ή πηγές θερμότητας.

### Αποθήκευση

Αποθηκεύστε σε δροσερό, ξηρό και αεριζόμενο περιβάλλον, μακριά από όζον, θερμότητα, λάδια και αιχμηρά αντικείμενα.

### Διάρκεια ζωής

Η διάρκεια ζωής εξαρτάται από τις συνθήκες εργασίας. Αντικαταστήστε αμέσως εάν εμφανιστούν ρωγμές, σκλήρυνση, φθορά της σόλας.

**Προσοχή:** Τα υποδήματα πρέπει να ελέγχονται ως προς την εφαρμογή τους πριν από κάθε χρήση.

Δήλωση συμμόρφωσης ΕΕ διαθέσιμη στον ιστότοπο: [www.inter-tools.gr](http://www.inter-tools.gr)

PPE Regulation 2016/425

EN ISO 20347:2022+A1:2024 OB SR